

CV	Fonction	Défaut	Préréglages													
			0	1	2	3	4	5	6	7	8	9	10	11	12	13
7	Version	13														
8	Fabricant	42														
17	Adresse longue (poids faible)															
18	Adresse longue (poids fort)															
29	Configuration décodeur	98	98	98	98	98	98	98	98	98	98	98	98	98	98	98
47	Préréglages															
107	Temps d'extinction	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70
108	Dimer	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10
109	Période PWM	14	14	14	14	14	10	10	14	14	14	14	14	14	14	14
111	Vitesse fade in, fade out	3	3	3	1	1	12	12	3	1	1	1	1	1	1	3
112	Vitesse clignotement	183	183	183	110	183	183	183	183	110	183	183	183	183	110	183
113	Configuration sortie 1	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
114	Configuration sortie 2	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
115	Configuration sortie 3	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
116	Configuration sortie 4	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
117	Configuration sortie 5	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
118	Configuration sortie 6	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
119	Configuration sortie 7	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
120	Configuration sortie 8	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
121	Configuration sortie 9	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
122	Configuration sortie 10	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
123	Configuration sortie 11	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
124	Configuration sortie 12	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
125	Configuration sortie 13	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
126	Configuration sortie 14	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
127	Configuration sortie 15	143	143	15	31	63	73	73	11	31	31	31	31	31	31	139
128	Configuration sortie 16	143	143	15	31	191	73	73	11	31	31	31	31	31	31	139
131	Type de signal 1, sorties 1 à 4	0	0	0	0	0	0	0	0	1	2	3	2	4	5	0
132	Type de signal 2, sorties 5 à 8	0	0	0	0	0	0	0	0	1	2	3	3	4	5	0
133	Type de signal 3, sorties 9 à 12	0	0	0	0	0	0	0	0	1	2	3	2	4	5	0
134	Type de signal 4, sorties 13 à 16	0	0	0	0	0	0	0	0	1	2	3	3	4	5	0
141	Touche 1 on, groupe A	1	1	1	1	0	255	255	1	0	0	0	0	0	0	1
142	Touche 1 on, groupe B	0	0	0	0	0	0	255	0	0	0	0	0	0	0	0
143	Mappage signal 1	0	0	0	0	0	0	0	0	1	1	1	3	1	1	0
144	Touche 1 off, groupe A	2	2	0	2	3	0	0	2	0	0	0	0	0	0	2
145	Touche 1 off, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
147	Touche 2 on, groupe A	4	4	2	4	0	0	0	4	0	0	0	0	0	0	4
148	Touche 2 on, groupe B	0	0	0	0	0	255	0	0	0	0	0	0	0	0	0
150	Touche 2 off, groupe A	8	8	0	8	12	0	0	8	0	0	0	0	0	0	8
151	Touche 2 off, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
153	Touche 3 on, groupe A	16	16	4	16	0	0	0	16	0	0	0	0	0	0	16
154	Touche 3 on, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
156	Touche 3 off, groupe A	32	32	0	32	48	0	0	32	0	0	0	0	0	0	32
157	Touche 3 off, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
159	Touche 4 on, groupe A	64	64	8	64	0	0	0	64	0	0	0	0	0	0	64
160	Touche 4 on, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
162	Touche 4 off, groupe A	128	128	0	128	192	0	0	128	0	0	0	0	0	0	128
163	Touche 4 off, groupe B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
165	Touche 5 on, groupe A	0	0	16	0	0	0	0	0	0	0	0	0	0	0	0
166	Touche 5 on, groupe B	1	1	0	1	0	0	0	1	0	0	0	0	0	0	1
167	Mappage signal 2	0	0	0	0	0	0	0	0	2	2	2	12	2	2	0
168	Touche 5 off, groupe A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
169	Touche 5 off, groupe B	2	2	0	2	3	0	0	2	0	0	0	0	0	0	2
171	Touche 6 on, groupe A	0	0	32	0	0	0	0	0	0	0	0	0	0	0	0
172	Touche 6 on, groupe B	4	4	0	4	0	0	0	4	0	0	0	0	0	0	4
174	Touche 6 off, groupe A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
175	Touche 6 off, groupe B	8	8	0	8	12	0	0	8	0	0	0	0	0	0	8
177	Touche 7 on, groupe A	0	0	64	0	0	0	0	0	0	0	0	0	0	0	0
178	Touche 7 on, groupe B	16	16	0	16	0	0	0	16	0	0	0	0	0	0	16

[illegible]